

Operative armchair with clear and decisive shapes. It represents an alternative value to softer seating. Grey and anthracite backrests provide perfect matching with black, white and green mesh and with the wide range of fabrics selected for this new collection.

CHAIRS WITH MECHANISM GCPT AND
ARMRESTS B3D
IN CONFORMITY TO UNI EN-1335 - TYPE B

CHAIRS WITH MECHANISM GYT1 AND
ARMRESTS B3D
IN CONFORMITY TO UNI EN-1335 - TYPE A

COMPONENTS



HELLO (OPERATIVE CHAIRS WITH MESH BACKREST)

SWIVEL BASE

Available in two choices:

- (PLN3) Black nylon base, 680 mm diameter, 5 spokes.

WHEELS

Black nylon castors (65 mm diameter) with zinc-coated steel pin, snap-fit. Rubberized wheels optional.

(OPTIONAL) Polyamide feet interchangeable with the wheels with the same pin for fixing to the base.

ELEVATION

All the gas columns comply with the DIN 4550 standard and exceed the 4th level.

MECHANISMS

Three available choices:

- (GT) – Gas Translator

The mechanism has a fused aluminum swivel plate fixed directly to the seat frame, and a gas lift seat height adjustment.

With this mechanism you can:

- adjust the height of the gas pistons;
- rotate the seat 360°;
- adjust seat depth, with 6 positions;

- (GCPT) Gas Permanent Contact Translator

Mechanism with movement backrest lockable in 5 positions with a tilting range of 20°.

With this mechanism you can:

- adjust the height of the gas pistons;
- rotate the seat 360°;
- adjust load intensity based on weight by using a knob system;
- use the anti-shock lever to lock or unlock the tilting movement of the backrest;
- adjust seat depth, with 6 positions;
- have a tilting range for the backrest of 20°.

- (GYT1) Gas Synchron Translator

Synchronized movement of seat-backrest lockable in 5 positions, with a tilting range of 22°.

With this mechanism you can:

- adjust the height of the gas pistons;
- rotate the seat 360°;
- adjust load intensity based on weight by using a crank system;
- use the anti-shock lever to lock or unlock the synchron;
- adjust seat depth, with 6 positions;
- have a tilting range for the backrest of 22°.

ARMRESTS

- (B3D) Armrests adjustable for height, depth and rotation, tubular chromed with an upper cover made from soft black polyurethane

SEAT

The frame is made of molded polypropylene, padded with fire-proof cold foam polyurethane class 1IM, 4 cm thick, density 60 kg/m³.

BACKREST

High resistance structure realized in nylon strengthened with fiber of glass. The backrest has got a nylon lumbar support with adjustable height for a personalized confort. The backrest is covered with mesh 560 gr/mq min. (R2- RETE BREAK) with high capacity load, it's made in technopolymer available with colours: white, green and black.

UPHOLSTERY

Check finishes and colours available in the LAS Colours Samples Card.

DIMENSIONS



UPHOLSTERY	FEATURES	AVAILABILITY
Poli		■
Ecopelle		■
Crepe		■
Stretch		■
Melange		■
Trevi		■
Lana		
Crazy by Flukso		■
Chili by Gabriel		
Taylor by Flukso		■
Go Check by Gabriel		■
Crisp by Gabriel		
Pelle		
Customer fabric		■

BACKREST MESH	FEATURES	AVAILABILITY
R1- Rete ROUND		
R2- Rete BREAK		■
R3- Rete GABRIEL		

SHIPPING SPECIFICATION	TECHNICAL FEATURES	FIRE-RETARDANT TEST	FABRIC RESISTANCE TEST
Standard chair+Armrests	Fabric used mtl 0,35 h.140	For specification, please you see the colour samples card. Contact us for more information.	For specification, please you see the colour samples card. Contact us for more information.
- Pcs. 2 - m³ 0,195 - Kg 18.5			



USE AND MAINTENANCE

GENERAL INFORMATION

Do not expose the seating to direct sunlight and keep it at least 30 cm from any heat source;
Do not sit with abrasive accessories, sharp objects in your pocket or jacket (keys, buttons, zippers, etc.) that may damage the fabric.
Fabrics can fade. It may happen that under certain circumstances, colored clothes or jeans may stain the upholstery.
Furthermore, the light colors of the fabrics and leathers are more susceptible to getting dirty.
Choose the correct wheels for the type of floor on which the chair will be used.
Rigid wheels on carpets or rugs (TYPE H) Soft wheels on hard ground: marble, tiles, ... etc.
Wheels should be cleaned from time to time with gauze to remove fluff and dust.

USE

This product is for indoor use only. The chair must be used in compliance with the aim for which it has been projected (office swivel chair) and with diligence. Improper use (e.g. climbing the chair with feet) may cause instability, falling down and/or serious injury to persons and objects.
Do not modify the chair in a way that could compromise its stability. Gas column substitution or reparation must be performed by trained staff only.

CLEANING AND MAINTENANCE

As a general rule, we recommend using cleaning products that do not harm the environment.
Follow the manufacturer's instructions for cleaning products.
Before cleaning stains, try, as far as possible, to perform a test on a hidden area.

FABRICS

POLI - CREPE - TREVI - STRETCH - MELANGE - LANA - CRISP

For normal maintenance and cleaning, use the vacuum cleaner with smooth spout regularly, don't brush.

TAYLOR F.R.

Use the smooth spout vacuum cleaner regularly without brushing.
Immediately remove food residues and any oil, milk and drink stains.
Dab quickly with absorbent paper and brush gently with water and neutral soap or 20% water and alcohol solution. **GENERAL WARNINGS**
The remedies indicated are effective in 90% of cases. The lack of timeliness in the action makes the cleaning less effective, resulting in the permanence of halos.

GO CHECK - CHILI - RETE ROUND - RETE BREAK - RETE GABRIEL

Use the smooth spout vacuum cleaner regularly without brushing. Immediately remove food residues and any oil, milk and drink stains.
Dab quickly with absorbent paper and wipe gently with water and neutral soap using a clean white cotton cloth.

ECOPELLE - CRAZY

Immediately absorb the stain with absorbent paper, then wipe with a damp cloth and neutral soap.
Dry immediately after treatment. Do not rub, but dab gently from the edges towards the center of the stain. Repeat the operation if necessary.
Absolutely avoid the use of products containing any type of solvents, bleaches, alcohol, chemical detergents and polishing sprays.

PELLE (REAL LEATHER)

Possible leather scratches and marks are not to be considered imperfections but a guarantee of its quality and authenticity.
Slight differences between dyeing lots are considered normal. For a normal cleaning, sprinkle with a soft, dry white cloth.
Any stains can be removed using a white cloth dampened with water and neutral soap.
After cleaning carefully, pass a damp cloth soaked in water, so as to remove any residue of detergent.
Dry immediately after treatment. Do not rub, but dab gently from the edges towards the center of the stain.
Do not dry in direct sunlight or with hair dryer.

METALS (STEEL OR ALUMINIUM)

To preserve the brilliant Chrome finish, regularly wipe with a soft clean cloth using only mild soap and water.
Do not use solvents or acids. Dry with a dry cotton cloth.
Polished aluminium undergoes a natural oxidation process, any stains can be removed using a soft wax suitable for metals.

PLASTIC MATERIAL

For normal maintenance and cleaning use a soft clean cloth with water and neutral soap.
Dry with a cotton cloth. Avoid using solvents.

PHASING OUT AND DISPOSAL OF THE PRODUCT

- At the end of their life cycle, the materials must not be left lying around in nature but consigned to the authorised disposal centres.

WARRANTY

The original buyer of LAS MOBILI s.r.l. chair unit is covered by a 5 (five) year warranty, starting from the day of purchase, with the following exceptions.
Exposed parts such as:



Omega Ekspres SIA

LV40003402577

Biroja adrese: Lāčplēša 125, LV-1003, Rīga

www.city-office.lv

info@city-office.lv

Covering warranty 3 (three) years

Padding warranty 2 (two) years

The LAS MOBILI s.r.l. warranty is expressly restricted to the replacement of parts and components of the chair.

For all other aspects consult the current price list

LAS MOBILI s.r.l.

Via dell'Industria, 81
64018 Tortoreto (TE) – Italy
Tel. +39 0861 7831
Fax +39 0861 786851
las@las.it – www.las.it

Since the Company is constantly committed to the improvement of its products, all descriptions, dimensions, indications etc. shown on this sheet are to be considered indicative. They can therefore be subject to change without notice and without this implying any responsibility on our part or that of our dealers.

A model which stands out as a reference point for its design and wide range available. Beautiful in any version, from the upholstered one to the mesh backrest, including the cantilever version. The headrest turns this chair into a semi-executive chair, performing and comfortable.

CHAIRS WITH MECHANISM GYT1 WITH
ARMRESTS B3D
IN CONFORMITY TO UNI EN-1335 - TYPE A

COMPONENTS



HELLO (PADDED OPERATIVE CHAIR)

Swivel base:

Available in two choices:

- (PLN3) Black nylon base, 680 mm diameter, 5 spokes.
- (ALC7) Polished die-cast aluminium base, 700 mm diameter, 5 spokes.

WHEELS

Black nylon castors (65 mm diameter) with zinc-coated steel pin, snap-fit. Rubberized wheels optional.

(OPTIONAL) Polyamide feet interchangeable with the wheels with the same pin for fixing to the base.

ELEVATION

All the gas columns comply with the DIN 4550 standard and exceed the 4th level.

MECHANISMS

Three available choices:

- (GT) – Gas Translator

The mechanism has a fused aluminum swivel plate fixed directly to the seat frame, and a gas lift seat height adjustment.

With this mechanism you can:

- adjust the height of the gas pistons;
- rotate the seat 360°;
- adjust seat depth, with 6 positions;

- (GCPT) Gas Permanent Contact Translator

Mechanism with movement backrest lockable in 5 positions with a tilting range of 20°.

With this mechanism you can:

- adjust the height of the gas pistons;
- rotate the seat 360°;
- adjust load intensity based on weight by using a knob system;
- use the anti-shock lever to lock or unlock the tilting movement of the backrest;
- adjust seat depth, with 6 positions;
- have a tilting range for the backrest of 20°.

- (GYT1) Gas Synchron Translator
Synchronized movement of seat-backrest lockable in 5 positions, with a tilting range of 22°.

With this

mechanism you can:

- adjust the height of the gas pistons;
- rotate the seat 360°;
- adjust load intensity based on weight by using a crank system;
- use the anti-shock lever to lock or unlock the synchron;
- adjust seat depth, with 6 positions;
- have a tilting range for the backrest of 22°.

ARMRESTS

- (B3D) Armrests adjustable for height, depth and rotation, tubular chromed with an upper cover made from soft black polyurethane.

SEAT

The frame is made of molded polypropylene, padded with fire-proof cold foam polyurethane class 1IM, 4 cm thick, density 60 kg/m³.

BACKREST

Visible external backrest made in molded resilient polypropylene, available in anthracite or grey, progressive flexibility; internally padded with fireproof cold foam polyurethane class 1IM, 4 cm thick, density 60 kg/m³, supported by a polypropylene rigid underframe. Inner lumbar support made with molded polypropylene, equipped with step-by-step movement regulation.

HEAD SUPPORT

Visible external cover made with molded resilient polypropylene, available in anthracite or grey, internally padded with fireproof cold foam polyurethane class 1IM, 15 mm thick, density 60 kg/m³, supported by a polypropylene rigid underframe made removable by the snapping coupling system.

UPHOLSTERY

Check finishes and colours available in the LAS Colours Samples Card.

DIMENSIONS



UPHOLSTERY	FEATURES	AVAILABILITY
Poli		■
Ecopelle		■
Crepe		■
Stretch		■
Melange		■
Trevi		■
Lana		
Crazy by Flukso		■
Chili by Gabriel		
Taylor by Flukso		■
Go Check by Gabriel		■
Crisp by Gabriel		
Pelle		
Customer fabric		■

SHIPPING SPECIFICATION	TECHNICAL FEATURES	FIRE-RETARDANT TEST	FABRIC RESISTANCE TEST
Version with headrest+armrests - Pcs. 2 - m³ 0,217 - Kg 22,5	Fabric used mtl 1,15 h.140	For specification, please you see the colour samples card. Coctact us for more information.	For specification, please you see the colour samples card. Coctact us for more information.
Standard version+armrests - Pcs. 2 - m³ 0,195 - Kg 20,5	Fabric used mtl 1,05 h.140		



USE AND MAINTENANCE

GENERAL INFORMATION

Do not expose the seating to direct sunlight and keep it at least 30 cm from any heat source;
Do not sit with abrasive accessories, sharp objects in your pocket or jacket (keys, buttons, zippers, etc.) that may damage the fabric.
Fabrics can fade. It may happen that under certain circumstances, colored clothes or jeans may stain the upholstery.
Furthermore, the light colors of the fabrics and leathers are more susceptible to getting dirty.
Choose the correct wheels for the type of floor on which the chair will be used.
Rigid wheels on carpets or rugs (TYPE H) Soft wheels on hard ground: marble, tiles, ... etc.
Wheels should be cleaned from time to time with gauze to remove fluff and dust.

USE

This product is for indoor use only. The chair must be used in compliance with the aim for which it has been projected (office swivel chair) and with diligence. Improper use (e.g. climbing the chair with feet) may cause instability, falling down and/or serious injury to persons and objects.
Do not modify the chair in a way that could compromise its stability. Gas column substitution or reparation must be performed by trained staff only.

CLEANING AND MAINTENANCE

As a general rule, we recommend using cleaning products that do not harm the environment.
Follow the manufacturer's instructions for cleaning products.
Before cleaning stains, try, as far as possible, to perform a test on a hidden area.

FABRICS

POLI - CREPE - TREVI - STRETCH - MELANGE – LANA - CRISP

For normal maintenance and cleaning, use the vacuum cleaner with smooth spout regularly, don't brush.

TAYLOR F.R.

Use the smooth spout vacuum cleaner regularly without brushing.
Immediately remove food residues and any oil, milk and drink stains.
Dab quickly with absorbent paper and brush gently with water and neutral soap or 20% water and alcohol solution. **GENERAL WARNINGS**
The remedies indicated are effective in 90% of cases. The lack of timeliness in the action makes the cleaning less effective, resulting in the permanence of halos.

GO CHECK – CHILI - RETE ROUND – RETE BREAK – RETE GABRIEL

Use the smooth spout vacuum cleaner regularly without brushing. Immediately remove food residues and any oil, milk and drink stains.
Dab quickly with absorbent paper and wipe gently with water and neutral soap using a clean white cotton cloth.

ECOPELLE - CRAZY

Immediately absorb the stain with absorbent paper, then wipe with a damp cloth and neutral soap.
Dry immediately after treatment. Do not rub, but dab gently from the edges towards the center of the stain. Repeat the operation if necessary.
Absolutely avoid the use of products containing any type of solvents, bleaches, alcohol, chemical detergents and polishing sprays.

PELLE (REAL LEATHER)

Possible leather scratches and marks are not to be considered imperfections but a guarantee of its quality and authenticity.
Slight differences between dying lots are considered normal. For a normal cleaning, sprinkle with a soft, dry white cloth.
Any stains can be removed using a white cloth dampened with water and neutral soap.
After cleaning carefully, pass a damp cloth soaked in water, so as to remove any residue of detergent.
Dry immediately after treatment. Do not rub, but dab gently from the edges towards the center of the stain.
Do not dry in direct sunlight or with hair dryer.

METALS (STEEL OR ALUMINIUM)

To preserve the brilliant Chrome finish, regularly wipe with a soft clean cloth using only mild soap and water.
Do not use solvents or acids. Dry with a dry cotton cloth.
Polished aluminium undergoes a natural oxidation process, any stains can be removed using a soft wax suitable for metals.

PLASTIC MATERIAL

For normal maintenance and cleaning use a soft clean cloth with water and neutral soap.
Dry with a cotton cloth. Avoid using solvents.

PHASING OUT AND DISPOSAL OF THE PRODUCT

- At the end of their life cycle, the materials must not be left lying around in nature but consigned to the authorised disposal centres.



Omega Ekspress SIA

LV40003402577

Biroja adrese: Lāčplēša 125, LV-1003, Rīga

www.city-office.lv

info@city-office.lv

WARRANTY

The original buyer of LAS MOBILI s.r.l. chair unit is covered by a 5 (five) year warranty , starting from the day of purchase, with the following exceptions.
Exposed parts such as:

Covering warranty 3 (three) years

Padding warranty 2 (two) years

The LAS MOBILI s.r.l. warranty is expressly restricted to the replacement of parts and components of the chair.

For all other aspects consult the current price list

LAS MOBILI s.r.l.

Via dell'Industria, 81
64018 Tortoreto (TE) – Italy

Tel. +39 0861 7831

Fax +39 0861 786851

las@las.it – www.las.it

Since the Company is constantly committed to the improvement of its products, all descriptions, dimensions, indications etc. shown on this sheet are to be considered indicative. They can therefore be subject to change without notice and without this implying any responsibility on our part or that of our dealers.